


**SMILEY REMOVAL INSTRUCTIONS**

1. REMOVE TRIM FROM COLLAR
2. PUT HAND THRU COLLAR AND DISCONNECT BOTH MOLEX CONNECTORS FROM DRIVER DOOR.

**NOTE:** THE SECOND MOLEX CONNECTOR WILL NOT BE PRESENT IF A PASSIVE HEATSINK IS USED FOR THE LED CHIP.

3. UNSCREW MOUNTING SCREWS 1 & 2 FROM SMILEY MOUNTING PLATE. SMILEY SUB ASSEMBLY CAN NOW BE REMOVED THRU HOUSING COLLAR.

**PROPRIETARY AND CONFIDENTIAL**  
 THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF SPECIALTY LIGHTING INDUSTRIES INC. ANY REPRODUCTION IN PART OR AS A WHOLE WITHOUT THE WRITTEN PERMISSION OF SPECIALTY LIGHTING INDUSTRIES INC. IS PROHIBITED.

		UNLESS OTHERWISE SPECIFIED:		NAME	DATE	 <b>SPECIALTY LIGHTING INDUSTRIES, INC.</b>	
		DIMENSIONS ARE IN INCHES TOLERANCES: FRACTIONAL: ± 1/64 ANGULAR: ± 0.5 TWO PLACE DECIMAL : ± .01 THREE PLACE DECIMAL: ± .005		DRAWN	JDF		10/21/14
		INTERPRET GEOMETRIC TOLERANCING PER:		CHECKED			
		MATERIAL		ENG APPR.			
NEXT ASSY	USED ON	FINISH		MFG APPR.			
APPLICATION		DO NOT SCALE DRAWING		Q.A.			
				COMMENTS:		TITLE:	
						SMILEY REMOVAL INSTRUCTIONS	
		SIZE	DWG. NO.			REV	
		<b>B</b>	1009-LEDB-PH-ZT - SRI			<b>A</b>	
		SCALE: 1:8	WEIGHT:			SHEET 1 OF 1	